

## Update Instructions

Dear customer,

While updating MS409, you will need to install **MaxiLink** program first. Please follow the steps below to do the update.

1. Install **MaxiLink** in your computer.  
You can find this file in the CD came with your scan tool.
2. Connect MS409 to your PC with the update cable.
3. If the connection is fine, you will find the status bar at the top of MaxiLink window become green.
4. Click "**Select File**" on the **MaxiLink** window to locate the update file.
5. Click "**Update**" to begin updating your tool. When update is done, the **MaxiLink** will pop up a message.
6. Power off the tool then on again to finish the update.

***NOTE: The DTC Lib Update is a little different from the program update. Please follow the instructions in the window to do.***